



TIMELESS DESIGN.
MODERN LIFE.

LEATHER CARE & CLEANING GUIDE

Proper care helps preserve the natural beauty, softness, and durability of your Gilman Creek Furniture leather.



QUICK SPILL RESPONSE

- 1**  **BLOT IMMEDIATELY**
Use a clean, absorbent cloth to blot spills as soon as they occur. Do not rub.
- 2**  **CLEAN GENTLY**
Use a soft cloth lightly dampened with the recommended soap-and-water solution.
- 3**  **LET DRY NATURALLY**
Pat dry with a clean cloth and allow the leather to air-dry completely.



EVERYDAY CARE



Dust weekly with a soft, lint-free cloth.



Vacuum seams and crevices regularly.



Keep furniture out of direct sunlight.



Keep at least 12 inches from heat sources.



CLEANING GUIDELINES

- Mix 2/3 distilled water with 1/3 gentle soap.
- Dampen a clean cloth and gently clean the area.
- Use a separate cloth dampened with plain water to remove soap residue.
- Pat dry and allow the leather to air-dry naturally.
- Test any cleaner or conditioner on an inconspicuous area first.



LEATHER CONDITIONING

Apply a leather furniture conditioner periodically to help prevent drying or cracking. Follow product directions carefully.

WHAT TYPE OF STAIN?



WATER-BASED STAINS

- Blot immediately.
- Clean using the soap-and-water steps above.
- Air dry.



OIL-BASED STAINS

- Blot immediately.
- Clean using the steps above.
- If additional treatment is needed, always spot-test first and follow product directions.



PLEASE NOTE:

Leather products may require more specialized care. Always test first and follow product instructions.



DO NOT USE



Bleach or ammonia



Solvents



Saddle soap or wax



Abrasive cleaners or brushes



Heat sources or hair dryers



Over-saturating with water



Always refer to the care instructions included with your specific product, as materials and finishes may vary.



MEMBER CARE

(888)-509-5381

costcoservice@gilmancreek.com

GilmanCreek.com

GCF_LCCG260929